



Notes:

1. All dimensions given in inches (mm).
2. Not To Scale.
3. For Sectional Indicator Trim (V-Series), see template 7088-1006.

RESPONSIBILITY
 DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

8800 Series Mortise Locks
 Wood and H.M. Door Preparation
 Thru Bolted Sectional Knob or Lever Trim
 1-855-557-5078 Ext. 2
 www.accentra-assaabloy.com

ACCENTRA
ASSA ABLOY

Experience a safer
 and more open world

Copyright © 2006, 2023, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES	1/24	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7088-1001	SHEET	DATE
		1 of 2	04/24

8800 Series		
Lock Function	Holes in Door	
8800	Outside	Inside
8801, 8870DT, 8871DT, 8872DT, 8880, 8881, 8884, 8885, 836 A & B, 838 A & B	A, E	A, E
8802, 8862	A, C, E, F	A, C, E, F (or D or L)*
8805, 8807, 8808, 8824, 8831, 8890, 8891	A, B, E	A, E
8808-2, 8811-2, 8812-2, 8817-2, 8818-2, 8830-2, 8860-2, 8894-2, 8895-2, 8896-2, 8897-2, 8898-2, 8899-2	A, B, E	A, B, E
8820, 8827, 8864	A, B, C, E	A, C, E, F (or D or L)*
8809, 8822, 8832, 8840, 8847, 8860, 8861, 8867, 8896, 8897, 8898, 8899	A, B, E	A, C, E, F (or D or L)*
8828	None	A, E
8833	B Only	A, E
8823, 8829	A, B, E	None
8813ST, 8815	B Only	C, F (or D or L)*
8813ST-2	B Only	B, C, F (or D or L)*
8814	B Only	None
8814-2, 8833-2	B Only	B Only
8865	A, C, E, F (or D or L)*	A, C, E, F (or D or L)*
8835	None	A, C, E, F (or D or L)*
8834, 8834-2	B Only	A, B, E

Hole Chart		
Hole	Size	Used For
A	Dia <u>1-1/8</u> (29)	Levers/Knobs
B	Dia <u>1-1/4</u> (32)	Cylinder
C	Dia <u>5/8</u> (16)	Thumbturn, Emergency Key, IND, or CIND
D	Dia <u>7/64</u> (2.8)	Square Thumbturn Attaching Screws
E	Dia <u>5/16</u> (8)	Rose Thru-Bolts
F	Dia <u>7/64</u> (2.8)	Standard Thumbturn Plate Attaching Screws
K	Dia <u>7/64</u> (2.8)	IND Attaching Screws
	1-1/8 (28.5) Apart	
L	Dia <u>7/64</u> (2.8) .953 (24.2) Apart	HA Lever Thumbturn Plate Attaching Screws

*Use D or L for non-standard thumbturn.

RESPONSIBILITY
DOOR AND FRAME MANUFACTURERS ARE RESPONSIBLE FOR PROVIDING ADEQUATE CONSTRUCTION OR REINFORCEMENTS FOR PROPER INSTALLATION OF HARDWARE SHOWN. ALL ARCHITECTURAL BUILDERS HARDWARE MUST BE INSTALLED ON PROPERLY REINFORCED DOORS AND FRAMES, REGARDLESS OF TYPE, MATERIAL, OR METHOD OF CONSTRUCTION.

8800 Series Mortise Locks

Wood and H.M. Door Preparation
Thru Bolted Sectional Knob or Lever Trim

1-855-557-5078 Ext. 2
www.accentra-assaabloy.com

ACCENTRA
ASSA ABLOY

Experience a safer
and more open world

Copyright © 2006, 2023, 2024, ASSA ABLOY ACCENTRA™ Access and Egress Hardware Group, Inc. All rights reserved. Reproduction in whole or in part without the express written permission of ASSA ABLOY Access and Egress Hardware Group, Inc. is prohibited.

SUPERSEDES	1/24	DO NOT SCALE DRAWING	
TEMPLATE NUMBER	7088-1001	SHEET	DATE
		2 of 2	04/24