




INSTALLATION INSTRUCTIONS

HS-1

Steel Hinge Shims



CROSS SECTION
DIMENSIONS

1. Apply pressure sensitive adhesive pad to shim(s), if desired, to hold in place during installation.
2. Place behind top, bottom, or all hinge leaves to shim door to achieve required clearances.
3. Use full length for continuous hinge applications. Break-off 3 1/2" sections for butt hinge applications.



POSITIVE
PRESSURE TESTED
MISCELLANEOUS
FIRE DOOR
ACCESSORY

5.26

ngp.com
1-800-NGP-RUSH

FAX: (800) 255-7874

QUOTES: quotes@ngp.com

ORDERS: orders@ngp.com