



OUTSIDE KNOB(LEVER) INSTALLATION INSTRUCTIONS

- Follow the drilling instructions on template. Drill 2-1/8" holes on inside and outside door faces.
- Follow the drilling instructions on template. Drill (2) 5/16" holes on outside door face for lever only.
- Insert knob (or lever) tail piece through 2-1/8" hole on outside door face.
- Cut off tail piece, if necessary, to have 3/16" projection beyond inside door face.
- Place inside mounting plate on inside door face and tighten 2 installation screws securely.
- Install push bar.

Notice: Do not remove the stud of the lever when connected with Exit Panic Device.

