


TEMPLATES & INSTALLATION INSTRUCTIONS GUIDE

Pull Side Closer Mounted on Door		
Arm Type	Template	Description
Regular	7316-1102	1600, Non-Hold Open or Hold Open
	7316-1108	1600, w/ 2403 Bracket (Molded/Bullnose Frame), Non-Hold Open
	7316-1110	1600, w/ 2403 3/4 Bracket (Molded/Bullnose Frame), Non-Hold Open
	7316-1112	1600, w/ 80 Bracket (Molded/Bullnose Frame), Hold Open
	7316-1149	1600, w/ 1647 (Corner Bracket), Non-Hold Open or Hold Open
Regular, Low Profile	7316-1106	1681, Non-Hold Open

Push Side Closer Mounted on Frame		
Arm Type	Template	Description
Top Jamb	7316-1152	J1600, Non-Hold Open or Hold Open
	7316-1158	J1600 w/ 1687 Drop Plate, Non-Hold Open or Hold Open
	7316-1162	J1680, w/ 1687 Drop Plate, Non-Hold Open
	7316-1160	J1600, w/ 1688 Drop Plate, Non-Hold Open, Hold Open
Unitrol®, Heavy-Duty	7316-2402	UNI1600, Non-Hold Open or Hold Open
	7316-2404	UNI1600, w/ 1687 Drop Plate, Non-Hold Open or Hold Open


Experience a safer
and more open world



TEMPLATES & INSTALLATION INSTRUCTIONS GUIDE

Push Side Closer Mounted on Door		
Arm Type	Template	Description
Parallel	7316-1202	P1600, Non-Hold Open or Hold Open
	7316-1214	P1600, w/ 2018 Soffit Plate, Non-Hold Open
	7316-1216	P1600, w/ 2018D Soffit Plate, Non-Hold Open
	7316-1208	P1600, w/ 2022 Flush Transom Bracket, Non-Hold Open or Hold Open
	7316-1210	P1600, w/ 2018S (Offset Soffit Plate), Non-Hold Open
	7316-1212	P1600, w/ 2018B Soffit Plate, Non-Hold Open
Parallel, Low Profile	7316-1206	P1680, Non-Hold Open
Parallel Rigid, Heavy-Duty	7316-1252	PR1600, Non-Hold Open or Hold pen
	7316-1254	PR1600, w/ 6890 Reinforcing Bracket, Non-Hold Open or Hold Open
	7316-1256	PR1600, w/ 2019L (Flush Transom Bracket), Non-Hold Open or Hold Open
Closer Plus®, Heavy-Duty	7316-2302	CLP1600, Non-Hold Open or Hold Open
	7316-2304	CLP1600, w/ 6890 Reinforcing Bracket, Non-Hold Open or Hold Open
	7316-2306	CLP1600, w/ 2019L (Flush Transom Bracket), Non-Hold Open or Hold Open with or without 1688 Drop Plate, Stop Only or Stop & Hold
Closer Plus Spring™, Heavy-Duty	7316-2302	CPS1600, Non-Hold Open or Hold Open
	7316-2304	CPS1600, w/ 6890 Reinforcing Bracket, Non-Hold Open or Hold Open
	7316-2306	CPS1600, w/ 2019L (Flush Transom Bracket), Non-Hold Open or Hold Open with or without 1688 Drop Plate, Stop Only or Stop & Hold
Unitrol®, Heavy-Duty	7316-2366	UNI1600, w/ 6191 Reinforcing Kit, Non-Hold Open or Hold Open, Door Widths 28" - 32"
	7316-2367	UNI1600, w/ 6191 Reinforcing Kit, Non-Hold Open or Hold Open, Door Widths 33" - 41"
	7316-2368	UNI1600, w/ 6191 Reinforcing Kit, Non-Hold Open or Hold Open, Door Widths 42"- 48"
	7316-2354	UNI1600, with 6190 Bracket, Non-Hold Open or Hold Open, Door Widths 28" - 32"
	7316-2355	UNI1600, with 6190 Bracket, Non-Hold Open or Hold Open, Door Widths 33" - 41"
	7316-2356	UNI1600, with 6190 Bracket, Non-Hold Open or Hold Open, Door Widths 42" - 48"
	7316-2360	UNI1600, Flush Partitions, w/ 2022 Bracket, Non-Hold Open or Hold Open , Door Widths 28" - 32"
	7316-2361	UNI1600, Flush Partitions, w/ 2022 Bracket, Non-Hold Open or Hold Open, Door Widths 33" - 41"
	7316-2362	UNI1600, Flush Partitions, w/ 2022 Bracket, Non-Hold Open or Hold Open, Door Widths 42" - 48"

Experience a safer
and more open world



TEMPLATES & INSTALLATION INSTRUCTIONS GUIDE

Pull Side Closer Mounted on Door		
Arm Type	Installation Instruction	Description
Regular	80-9316-2531-020	1601, 1603BC, 1604BC, Non Hold Open
	80-9316-3532-020	1601, 1603BC, 1604BC, Hold Open
	80-9316-2535-020	1601SS, 1603BCSS, 1604BCSS, Non Hold Open
Regular, Low Profile	80-9316-2536-020	1681, 1683BC, 1684BC, Non Hold Open

Push Side Closer Mounted on Frame		
Arm Type	Installation Instruction	Description
Top Jamb	80-9316-2531-020	1601, 1603BC, 1604BC, Non Hold Open
	80-9316-3532-020	1601, 1603BC, 1604BC, Hold Open
	80-9316-2535-020	1601SS, 1603BCSS, 1604BCSS, Non Hold Open
Unitrol®, Heavy-Duty	80-9316-2534-020	UNI-J1601, UNI-J1603BC, UNI-J1604BC, Non Hold Open and Hold Open

Push Side Closer Mounted on Door		
Arm Type	Installation Instruction	Description
Parallel	80-9316-2531-020	1601, 1603BC, 1604BC, Non Hold Open
	80-9316-3532-020	1601, 1603BC, 1604BC, Hold Open
	80-9316-2535-020	1601SS, 1603BCSS, 1604BCSS, Non Hold Open
Parallel, Low Profile	80-9316-2536-020	1681, 1683BC, 1684BC, Non Hold Open
Parallel Rigid, Heavy-Duty	80-9316-2537-020	PR1601, PR1603BC, PR1604BC, Non-Hold Open or Hold Open
Closer Plus®, Heavy-Duty		CLP1601, CLP1603BC, CLP1604BC, Non-Hold Open or Hold Open
Cushion Stop, Heavy-Duty	80-9316-2538-020	CA1601, CA1603BC, CA1604BC, Non-Hold Open
Unitrol®, Heavy-Duty	80-9316-2533-020	UNI-1601, UNI-1603BC, UNI-1604BC, Non-Hold Open and Hold Open

Adapter Plate	
Installation Instruction	Description
80-9316-0604-020	1699 Adapter Plate for 1601, 1603BC, 1604BC, Regular Arm, Top Jamb, and Parallel Arm Applications

Experience a safer
and more open world